


ACEBEAM

Light Where You Want It

User Manual



L35 2.0

IMMENSE OUTPUT TACTICAL
FLASHLIGHT WITH DUAL SWITCH

Features

- Powerful pocket tactical flashlight with breakthrough 5000 lumens
- Maximum beam intensity of 105625cd and maximum throw of 650 meters
- Equipped with one single Cree XHP70.3 HI LED
- Powered by a 21700 battery, Acebeam USB-C rechargeable 21700 Li-ion battery included
- The customized TIR lens provides better light quality with a soft and balanced beam
- The aggressive strike bezel is used to break windows or defend in an emergency situation
- Dual switches for easy and fast operation
- Strobe mode for law enforcement
- The power indicator indicates the remaining battery power
- Lockout mode prevents accidental activation
- Highly efficient constant current circuit design (Non-PWM)
- Intelligent temperature regulation and protection adjusts output performance to prevent overheating
- Made of Aerospace-grade aluminum body with HAIII military hard-anodized finish
- 1-meter impact resistance and waterproof rate to 5 meters submersible

Specifications

Dimensions: 152mm (Length) x 54,2mm (Head Diameter) x 25,4mm (Tube Diameter)

Weight: 250g w/ battery

Accessories

1x Holster, 1x Pocket clip, 1x Lanyard, 1x Spare rubber button cap, 2x O-rings, 1x Warranty card, 1x User manual

Technical Parameter

	STANDARD	Turbo	High	Mid 2	Mid 1	Low	Moonlight	Strobe	
CREE XHP70.3 HI		5000-1800 lumens	1800 lumens	800 lumens	230 lumens	80 lumens	1 lumen	1800 lumens	
		1m/1h 1h 15min	1h 30min	4h	12h 45min	33h 30min	12days	2h 30min	
		650m	370m	250m	150m	90m		370m	
		105625cd	34225cd	15625cd	5625cd	2025cd		34225cd	

Notice: The above mentioned parameters (tested with 1x ACEBEAM 21700 battery) are approximate and may vary from flashlights, batteries, and environments. The L35 2.0 needs to be installed 1x 21700 high drain battery that can produce at least 20 Amps of current.

Operation Instruction

Tactical Tail Switch:

When the flashlight is Unlocked, click the tactical tail switch for momentary on and constant activation at Turbo mode.

Please note if click the tactical tail switch at first, Any operation of side switch is useless.

Side Switch:

ON/OFF: Single click the side switch.

Mode Selection: When the flashlight is ON, press and hold the side switch to cycle from Low →Med1 →Med2 →High modes, loosen the switch at your selected mode, Next ON will memorize the last mode you selected.

Turbo: Double click the side switch to exchange between Turbo mode and memorized mode, **Strobe:** Triple click to access Strobe mode regardless the flashlight is ON or OFF.

Moonlight: When the flashlight is OFF, press and hold the side switch for 0.5 second goes to moonlight.

Lock

When the flashlight is OFF, press and hold the side switch for 5 seconds, the flashlight will be Locked after 3 seconds' Moonlight output, It is useless for both side switch operation and tactical tail switch.

Unlock

When the flashlight is Locked, press and hold the side switch for 3 seconds, the flashlight will be Unlocked and light at Moonlight mode.

(Remark: To unlock, the tail switch needs to be turned off firstly, the power indicator can indicate the tail switch is on or off)

Moonlight and Turbo can not be memorized.

Power Indicator

Green light: >30%

Red light: among 30%~ 10%, low battery warning

Red flash light: below 10%

Warning

1. By using this device, you certify you have read the included User Manual and Warning Card and release the manufacturer and retailers from all liabilities.
2. Please use in accordance with applicable laws and regulations.
3. Quality batteries with circuit protection will reduce the potential risk.
4. Do not aim this light directly at eyes or exposed skin to prevent injuries. Keep this flashlight out of the reach of children.

Usage and Maintenance

1. Unauthorized disassembly may damage the light and void the warranty.
2. This is normal case the light will accumulate a lot of heat when used on Turbo/output levels for extended periods.
3. Lubricate the threads with professional grade lubricant regularly.
4. Please swap out the O-rings regularly to maintain the water resistance level.
5. Maintain and keep clean any contact surfaces of the flashlight with alcohol swab. This may prevent irregular flashes during use.
6. Remove batteries during storage, Keep lithium-ion batteries charges approximately every 4 months.
7. This flashlight may not be used as diving light.

Product Warranty

1. If the customer experiences any problems with an Acebeam product within 15 days of purchase, the dealer will replace that product.
2. If an Acebeam flashlight fails during normal use within a period of five years (60 months) of purchase, the dealer will repair or replace the flashlight with the same or similar model.
3. ACEBEAM Batteries, accessories and lanterns with built-in batteries are warranted for a period of one year (12 months) from date of purchase.
4. The warranty does not cover damage or failure caused by:
 - A. Rough usage or operation which does not comply with the user manual or product specifications.
 - B. Unauthorized disassembly, repair or modification, Defects or damaged caused by factors out of Acebeam's control.
 - C. Battery leakage damaged products.
5. If there are any questions about Acebeam products, please consider the warranty and contact Acebeam or your original Acebeam dealer for warranty return instructions, Email: info@acebeam.com

Acebeam is not liable for damages or injuries sustained resulting from the usage of the product inconsistent with the warnings in the manual.



SHENZHEN ZENBON TECHNOLOGY CO., LTD

+86-0755-23036551

www.acebeam.com

info@acebeam.com

1/F, No.1 Building, Yijayang Industrial Park, Dalang,
Longhua, Shenzhen 518100, Guangdong, China

Copyright © 2024 ACEBEAM. All rights reserved.
Powered by Shenzhen Zenbon Technology Co., Ltd